

# Drumtrigger

4 Channel Pad to Midi Converter

Sensitivity Control

Ch1 Ch2 Ch3 Ch4

● Power

● MIDI Activity

Menu Control

OK

